






size	"44.27"	CVI 06 L
size	"57.27"	CVI 10 L
size	"77.27"	CVI 16 L
size	"104.27"	CVI 24 L

size "57.27" CVI 10 size "77.27" CVI 16 size "104.27" CVI 24

V-type locking system movements

OPEN




Lift the levers.






Position the connector.



Lower the levers.




Hook the levers to the pegs.





Extract the connector.



Lower the levers until the device clicks into the locked position.

SUMMIT